

Cuetec Weight Adjustment instructions

1. Unscrew the chrome butt cap with the bumper attached.



2. Unscrew weight adjustment cavity with a flat or Phillips head screwdriver



3. Insert the desired weight you want and reattach the bumper. Weights available in ½-oz (#13-9960) and 1-oz (#13-9966) in packages of 5.

